



A 16

Stud Welding Gun

93-20-280C



Operating Manual



After-sales service for Germany:

**HBS Bolzenschweiss-Systeme GmbH & Co. KG
Felix-Wankel-Strasse 18
85221 DACHAU
GERMANY**

**Phone +49 8131 511-0
Fax +49 8131 511-100
E-mail international@hbs-info.com
Web www.hbs-info.com**

A 16 Operating Manual Issue 2018-01 Order No. E-BA 93-20-280C

Translation of the Original Operating Manual

Please keep the manual in a safe place for future reference.

Transmission and duplication of this document, dissemination and notification of the contents are not permitted unless expressly approved.

All rights, errors and technical amendments reserved.

© HBS Bolzenschweiss-Systeme GmbH & Co. KG



Dear Customer,

Many thanks for buying a stud welding machine from HBS Bolzenschweiss-Systeme.

We at HBS wish you success at all times when working with this stud welding machine.

The high level of quality of our products is guaranteed by ongoing further development in the design, equipment and accessories. This may result in differences between the present operating manual and your product. No claims can therefore be derived from the data, illustrations and descriptions.

We have compiled the data and information in this reference work with the greatest care, and have made every effort to ensure that the information contained in this manual was correct and up-to-date at the time of delivery. We can nevertheless give no guarantee for an absolutely error-free document.

Should you discover any errors or unclear points when reading this operating manual, please do not hesitate to contact us.

We would also be grateful for any feedback should you have any suggestions or complaints to make about our product.

HBS Bolzenschweiss-Systeme GmbH & Co. KG

Felix-Wankel-Strasse 18

85221 Dachau

GERMANY



Table of Contents

1	Important Safety Precautions	6
2	Symbols and Terms Used	9
3	Scope of Supply	12
4	Accessories	12
5	Technical Data	13
6	Intended Use	17
7	Warranty	18
8	Design and Function	19
9	Welding Process	20
10	Preparing the Stud Welding Gun	21
10.1	Drawn Arc Stud Welding (Ceramic Application)	21
10.2	Drawn Arc Stud Welding (Shielding Gas Application)	25
10.3	Setting the Welding Parameters	28
	Adjusting Lift	30
	Setting the Insertion Depth (Protrusion)	31
11	Welding	33
12	Troubleshooting	34
13	Maintenance and Care	36
13.1	Cleaning	36
13.2	Inspection and Tests	37
13.3	Adjusting the Lift Scale	38



14	Storage	39
15	Disposal	39
	Declaration of Incorporation of partly completed Machinery	40
	Service & Support	41
	Index	42

1 Important Safety Precautions

The target group for this manual are qualified personnel who in view of their technical training, know-how and experience and knowledge of applicable regulations are able to assess the work assigned to them and recognise potential hazards.



Danger from incorrect use

- ◆ Use the stud welding machine only for the purpose described in this manual.

Otherwise you may endanger yourself or damage the stud welding machine.

You endanger yourself and others if you operate the stud welding machine incorrectly or fail to observe the safety precautions and warnings. This can lead to serious injury or extensive material damage.



Danger for unauthorised operating personnel

- ◆ Work with the stud welding machine only when
 - You are appropriately trained, instructed and authorised to do so, and
 - You have read and completely understood this operating manual.
- ◆ Never work with the stud welding machine when you are under the influence of
 - Alcohol,
 - Drugs or
 - Medication.



Danger from unauthorised modifications

- ◆ Never modify the stud welding machine or parts thereof without obtaining a clearance certificate from the manufacturer.

You will otherwise endanger yourself. This can lead to serious injury or extensive material damage.



Life-threatening danger for wearers of active implanted cardiac devices

- ◆ Never operate the stud welding machine if you wear a heart pace-maker or implanted defibrillator.
- ◆ In this case, never remain in the vicinity of the stud welding machine during welding.
- ◆ Never operate the stud welding machine if persons with heart pace-makers or implanted defibrillators are in the vicinity.

Strong electromagnetic fields are produced in the vicinity of the stud welding machine during welding. These fields could impact the function of heart pacemakers or implanted defibrillators.



Danger from fumes and airborne particulates

- ◆ Switch on the welding fume extractor at the place of work.
- ◆ Ensure that the room is well ventilated.
- ◆ Never weld in rooms with a ceiling height of less than 3 m.
- ◆ Observe furthermore your working instructions and the accident prevention regulations.

This will help to avoid health damage due to fumes and airborne particulates.



Danger from glowing metal spatter (fire hazard)

Glowing hot weld spatter and liquid splashes, flashes of light and a loud bang > 90 dB (A) must be anticipated during stud welding.

- ◆ Inform colleagues working in the immediate vicinity accordingly before starting work.
- ◆ Ensure that an approved fire extinguisher is available at the workplace.



- ◆ Do not weld when wearing working clothes soiled with flammable substances such as oil, grease, petroleum, etc.
- ◆ Wear your proper protective clothing, such as:
 - Protective gloves in accordance with the relevant standard,
 - Non-flammable clothing,
 - A protective apron over your clothing,
 - Full-ear hearing protection in accordance with the relevant standard,
 - A safety helmet when welding above your head,
 - Safety shoes,
 - Safety goggles with sight glass of protection level 2 in compliance with the applicable standards and do not look directly into the light arc.
- ◆ Remove all flammable materials and liquids from the vicinity of the work area before starting welding.
- ◆ Weld at a safe distance from flammable materials or liquids. Select a safety distance large enough to ensure that no danger can arise from weld spatter.



Protection of the stud welding unit

- ◆ Protect the stud welding machine against the ingress of foreign matter and liquids caused by cutting or grinding work in the vicinity of your work area.

This will help to prolong the service life of your stud welding machine.

2 Symbols and Terms Used

The symbols used in this operating manual have the following meanings:



Danger

Warns you of hazards that can lead to **injury of persons** or to **considerable material damage**.



Caution

Problems with the operating procedures **can occur** if this information is **not observed**.



No access for people with active implanted cardiac devices



Danger

Warns you of **electrical** hazards



Danger

Warns you of **electromagnetic fields** that can be generated during welding



These symbols prompt you to wear **personal protective clothing when working with the stud welding unit**.



This symbol prompts you to wear **ear protection**. **A loud bang > 90 dB (A) can occur during the welding process**.



Tip

Cross-reference to useful information on the use of the stud welding machine



Cross-references in this operating manual are marked with this symbol or *are printed in italics*



Fire hazard

Have a suitable fire extinguisher for the working area ready before starting work.



Work instruction



List


Glossary

Automatic welding head:	Device for welding of welding elements
Capacitor:	Component for storage of electrical energy.
Light arc:	Independent gas discharge between two electrodes when the current is high enough. A whitish light is emitted in the process. The light arc allows very high temperatures to be generated.
Rectifier:	Electrical component that converts alternating voltage into direct voltage
Stud feeder:	Device for automatic feeding of welding elements
Stud welding gun:	Device for welding of welding elements
Stud welding machine:	Stud welding unit including stud welding gun
Stud welding unit:	Device for provision of the electrical energy for stud welding
Thyristor:	Electronic component for contact-free switching of high currents; switching takes place via the control input
Welding element:	Component such as stud or pin that is welded to the workpiece
Welding parameters:	Mechanical and electrical settings at the stud welding gun and at the stud welding unit (e.g. spring force, charging voltage)
Workpiece:	Components such as sheet metal or tubes to which the welding elements are to be fastened

3 Scope of Supply

The **basic configuration** of your welding gun contains the following parts:

No. of pieces	Part	Type	Order No.
1	Welding gun cable length 4.85 m	A 16	93-20-280C
1	Operating manual	A 16	E-BA 93-20-280C



- ◆ Inspect the shipment for visible damage and completeness immediately on receipt.
- ◆ Report any transport damage or missing components immediately to the delivering shipping agent or the dealer (address, see page 2).

4 Accessories

For example:

Mounting tool set	93-40-116
Protective hose, complete with zipper	80-11-430

Additional accessories can be found in our extensive accessories catalogue.

5 Technical Data

Stud welding gun type A 16 (damped)

for ARC stud welding according to current standards

Welding range	Dia. 3 to 16 mm
Stud length	10 to 300 mm (depending on leg assembly)
Stud material	Mild steel, stainless steel
Stud type	Any type or shape (special chucks if required)
Length compensation	6 mm automatic
Lift	Adjustment range 4 mm, (0.25 mm steps, arresting)
Damping	Adjustable oildamper
Welding cable	4.85 m, 50 mm ²
IP Code	IP 20 (protect against humidity)
Workplace noise level	Up to 90 dB (A) may occur during welding
Ambient temperature limits	0 °C to 40 °C
Dimension L x B x H	260 x 74 x 220 mm (without cable, with tripod leg guidance)
Weight	2 kg (without cable), 4.6 kg (with cable)

Ceramic leg assembly

(not included in delivery)

for stud welding with ceramic ferrule according to current standards

Ceramic leg assembly PSC-2 Order no. 93-40-028



Welding range	Welding elements (RD, DD, PD, UD, ID) dia. 4 to 12 mm Shear connectors (SD) up to dia. 13 mm
Stud length	up to 170 mm
Dimension tripod legs	10 x 240 mm
Dimension food piece	Inner diameter d = 22 mm
Weight	0.397 kg

Ceramic leg assembly PSC-2 Order no. 93-40-040



Welding range	Welding elements (RD, DD, PD, UD, ID) dia. 16 to 20 mm Shear connectors (SD) up to dia. 13 mm
Stud length	up to 150 mm
Dimension tripod legs	10 x 240 mm
Dimension food piece	Inner diameter d = 28 mm
Weight	0.388 kg

Ceramic leg assembly PSC-2 Order no. 93-40-041

Welding range	Shear connectors (SD) dia. 16 mm
Stud length	up to 150 mm
Dimension tripod legs	10 x 240 mm
Dimension food piece	Inner diameter d = 29 mm
Weight	0.380 kg

Ceramic leg assembly PSC-2 Order no. 93-40-074

Welding range	Shear connectors (SD) dia. 16 mm
Stud length	up to 300 mm
Dimension tripod legs	10 x 390 mm
Dimension food piece	Inner diameter d = 29 mm
Weight	0.551 kg


Shielding gas leg assembly

(not included in delivery)

for stud welding with shielding gas according to current standards

Shielding gas leg assembly PSS-3

Order no. 93-40-017



Welding range

Welding elements (RD, DD, PD, UD, ID, PS, US, IS) dia. 6 to 16 mm

Stud length

up to 150 mm

Dimension tripod legs

10 x 240 mm

Dimension

D = 35 mm, l = 60 mm

Weight

0.960 kg

6 Intended Use

The stud welding gun has been designed exclusively for use with standardised stud welding elements. The use of any other elements will result in the desired strength of the welded joint being diminished.

The stud welding gun must only be connected to HBS stud welding units.

- ◆ Always check with the operating manual of your stud welding unit whether this stud welding gun may be used.

Observation of the operating manual of the stud welding unit being used is also part of the intended use.



7 Warranty

Please refer to the latest "General Terms and Conditions" for the scope of the warranty.


The warranty does not cover faults caused by e.g.

- Normal wear,
- Improper handling,
- Failure to observe the operating manual,
- Failure to observe the safety precautions,
- Use for other than the intended purpose, or
- Transport damage.

Warranty entitlement shall no longer be valid if modifications, changes or service and repair work is carried out by unauthorised persons or without the knowledge of the manufacturer. Invalidation of warranty entitlement shall also render the declaration of conformity invalid. The CE marking shall be declared invalid by the manufacturer.

We expressly point out that only spare parts and accessories or components approved by us may be used. The same applies likewise to installed units from our sub-suppliers.

8 Design and Function



The body of the welding gun consists of a sturdy two-part **plastic housing (1)**.

The **control cable (2)** and the **welding cable (3)** are connected through the welding gun handle to the welding gun.

Positioned at the front of the stud welding gun is a **double nipple (5)** used to fix the manual chuck.

At the front of the stud welding gun, the **tripod leg guidance (7)** is installed. Here the leg assembly is mounted.

The **protection cap (6)** is used to cover the damper.

At the rear (under the **cap (8)**), there is the mechanism for lift adjustment.

At the front of the welding gun handle, the **welding gun trigger (4)** is installed. It is used to trigger the welding process.

The serial number is stamped on the welding gun handle.

Type plate

The type plate contains the following information:

- Manufacturer
- Type



9 Welding Process

This stud welding gun may only be used for drawn arc stud welding.

- ◆ Please refer to the original operating manual of the connected stud welding unit for the welding procedure.

10 Preparing the Stud Welding Gun

Prepare the stud welding gun by

- mounting the leg assembly
- mounting the chuck
- adjusting the lift
- adjusting the insertion depth (protrusion).



- ◆ Do not connect the stud welding gun to the stud welding unit **until it has been prepared.**

In this way you can avoid any unintentional starting of the welding process.

10.1 Drawn Arc Stud Welding (Ceramic Application)

- ◆ Select a leg assembly suitable for your welding element:



Ceramic leg assembly PSC-2

Order no.: 93-40-028
(d = 22 mm)

for welding elements (RD, DD, PD, UD, ID)
dia. 4 to 12 mm
for shear connectors (SD) up to dia. 13 mm
up to length 170 mm



Ceramic leg assembly PSC-2

Order no.: 93-40-040
(d = 28 mm)

for welding elements (RD, DD, PD, UD, ID)
dia. 16 to 20 mm
for shear connectors (SD) up to dia. 13 mm
up to length 150 mm



Ceramic leg assembly PSC-2

Order no.: 93-40-041
(d = 29 mm)

for shear connectors (SD)
dia. 16 mm up to length 150 mm



Ceramic leg assembly PSC-2



Order no.: 93-40-074
(d = 29 mm)

for shear connectors (SD)
dia. 16 mm up to length 300 mm




◆ Select a chuck suitable for your welding element:

Welding elements for drawn arc stud welding (ceramic application):



Threaded studs with reduced shaft (RD)




Stud dimension $\varnothing d_1$	Chuck	Depth for studs in mm	Ceramic ferrule grip	Suitable leg assembly
M6	83-50-006	7	80-31-095	93-40-028
M8	83-50-008	9	80-31-120	93-40-028
M10	83-50-010	11	80-31-150	93-40-028
M12	83-50-012	13	80-31-170	93-40-028
M16	83-50-016	15	80-30-116	93-40-040



Virtually threaded studs (DD)




Stud dimension $\varnothing d_1$	Chuck	Depth for studs in mm	Ceramic ferrule grip	Suitable leg assembly
M6	83-50-006	7	80-31-095	93-40-028
M8	83-50-008	9	80-31-150	93-40-028
M10	83-50-010	11	80-31-150	93-40-028
M12	83-50-012	13	80-31-205	93-40-028
M16	83-50-016	15	80-31-262	93-40-040



Partially threaded studs (PD)



Stud dimension $\varnothing d_1$	Chuck	Depth for studs in mm	Ceramic ferrule grip	Suitable leg assembly
M6	83-50-006	7	80-31-095	93-40-028
M8	83-50-008	9	80-31-120	93-40-028
M10	83-50-010	11	80-31-150	93-40-028
M12	83-50-012	13	80-31-170	93-40-028
M16	83-50-016	15	80-30-116	93-40-040



Unthreaded studs (pins) (UD)



Stud dimension $\varnothing d_1$	Chuck	Depth for studs in mm	Ceramic ferrule grip	Suitable leg assembly
6	83-50-006	7	80-31-095	93-40-028
8	83-50-008	9	80-31-150	93-40-028
10	83-50-010	11	80-31-150	93-40-028
12	83-50-012	13	80-31-205	93-40-028
16	83-50-016	15	80-31-262	93-40-040



Studs with internal thread (ID)



Stud dimension $\varnothing d_2$	$\varnothing d_1$	Chuck	Depth for studs in mm	Ceramic ferrule grip	Suitable leg assembly
10	M5	83-50-010	11	80-31-150	93-40-028
10	M6	83-50-010	11	80-31-150	93-40-028
12	M8	83-50-012	13	80-31-205	93-40-028
16	M10	83-50-016	15	80-31-262	93-40-040


Shear connectors (SD)

Stud dimension $\varnothing d_2$	$\varnothing d_1$	Chuck	Depth for studs in mm	Ceramic ferrule grip	Suitable leg assembly
6	12,5	83-53-006	6	80-30-206	93-40-028
9,5	19	83-53-010	9	80-30-210	93-40-028
10	19	83-53-010	9	80-30-210	93-40-028
12,7	25	83-53-012	8	80-30-213	93-40-028
13	25	83-53-012	8	80-30-213	93-40-040
13	25	83-53-012	8	80-31-213	93-40-028
16	32	83-53-019	12	80-30-219	93-40-041 / 93-40-074





Mounting the chuck




- ◆ Screw the chuck on the thread socket of the welding gun.
- ◆ Tighten the chuck firmly with a double open ended-wrench AF 14/17 or 19/22 (accessory).


Mounting the leg assembly



- 1 - Wing screw
- ◆ Loosen the wing screw (1).




- 1 - Wing screw
- 2 - Tripod leg
- ◆ Now attach the leg assembly to the stud welding gun.
- ◆ Clamp the tripod legs (2) with the wing screw (1).




- 3 - Welding element
- ◆ Put the welding element up to the stop into the chuck.

Attention:
The welding element must firmly sit in the chuck, otherwise welding element and chuck would burn.



- 4 - Ceramic ferrule grip
- ◆ Place the ceramic ferrule grip into the foot piece.
- ◆ Clamp the ceramic ferrule grip with an allen key 3 mm (included in accessories).



- ◆ Put on the ceramic ferrule (5).
- ◆ Adjust the foot piece until the stud can be moved in the ceramic ferrule without friction (centered).
- ◆ Tighten the foot piece with an allen key 4 mm (accessory).
- ◆ Clamp the tripod legs with the wing screw.

10.2 Drawn Arc Stud Welding (Shielding Gas Application)

- ◆ Select a leg assembly suitable for your welding element:



Shielding gas leg assembly PSS-3


Order no.: 93-40-017
(D = 35 mm)

for welding elements (RD, DD, PD, UD, ID, PS, US, IS) dia. 6 to 16 mm

- ◆ Select a chuck suitable for your welding element:

Welding elements for drawn arc stud welding (shielding gas application):

**Threaded studs with reduced shaft (RD and DD)
Partially threaded studs (PD)**




Stud dimension
Ø d₁



Stud dimension Ø d ₁	Chuck	Depth for stud in mm
M6	83-51-006	7
M8	83-51-008	9
M10	83-51-010	11
M12	83-51-012	13
M16	83-51-016	16

Unthreaded studs (pins) (UD)




Stud dimension
Ø d₁



Stud dimension Ø d ₁	Chuck	Depth for stud in mm
6	83-51-006	7
8	83-51-008	9
10	83-51-010	11
12	83-51-012	13
16	83-51-016	16

Studs with internal thread (ID)




Stud dimension



Ø d ₂	Ø d ₁	Chuck	Depth for stud in mm
10	M5	83-51-010	11
10	M6	83-51-010	11
12	M8	83-51-012	13
16	M10	83-51-016	16

Threaded studs with flange (PS)




Stud dimension

$\varnothing d_1$	$\varnothing d_2$
M6	7
M8	9
M10	11



Chuck	Depth for stud in mm
83-51-006	7
83-51-008	9
83-51-010	11

Unthreaded studs (pins) with flange (US)




Stud dimension

$\varnothing d_1$	$\varnothing d_2$
6	7
7.1	9
8	9



Chuck	Depth for stud in mm
83-51-006	7
83-51-008	9
83-51-010	11

Studs with internal thread and flange (IS)





Stud dimension

$\varnothing d_1$	$\varnothing D_6$
6	M4
7.1	M5
8	M5
8	M6



Chuck	Depth for stud in mm
83-51-006	7
83-51-071	9
83-51-008	9
83-51-008	9

Mounting the chuck




- ◆ Screw the chuck on the thread socket of the welding gun.
- ◆ Tighten the chuck firmly with a double open ended-wrench AF 14/17 or 19/22 (accessories).

- ◆ Put the welding element up to the stop into the chuck.

Attention:


The welding element must firmly sit in the chuck, otherwise welding element and chuck would burn.

Mounting the leg assembly




1 - Wing screw

◆ Loosen the wing screw (1).



2 - Tripod leg

◆ Now attach the leg assembly to the stud welding gun.







◆ Clamp the tripod legs (2) with the wing screw (1).

10.3 Setting the Welding Parameters

The insertion depth, lift and hydraulic damping are, among others, dependent on the workpiece and welding elements used and their diameters.

The specifications in the following table are guidelines.

- ◆ Select the applicable parameters for insertion depth, lift and hydraulic damping for your workpiece.

Welding elements Material: 4.8 (suitable for welding) / A2-50 ⁴⁾	Diameter of welding elements				ARC 500, ARC 800, ARC 1550, IT 50, IT 90, IT 130, IT 1002, IT 2002, IT 3002 Welding gun parameters A 16 ¹⁾		
	metric ⁵⁾		imperial (US)		Insertion depth P in mm	Lift L in mm	
	Stud-diameter in mm	eff. diameter in mm	Stud-diameter in inches (ca.)	eff. diameter in inches (ca.)			
Material of workpiece: Mild steel (suitable for welding) / stainless steel (suitable for welding) ⁴⁾							
	RD ²⁾	Ø d ₁	Ø d ₂	Ø d ₁	Ø d ₂		
		M6	4.7	1/4	0.187	2.0	1.0
		M8	6.2	5/16	0.275	2.0	1.0
		M10	7.9	3/8	0.312	2.5	1.25
		M12	9.5	1/2	0.435	3.0	1.5
		M16	13.2	5/8	0.500	3.0	2.0
	PD/DD (MD) ²⁾	Ø d ₁	Ø d ₂	Ø d ₁	Ø d ₂		
		M6	5.35	1/4	0.21	2.0	1.0
		M8	7.19	5/16	0.28	2.5	1.25
		M10	9.03	3/8	0.36	3.0	1.5
		M12	10.86	1/2	0.43	3.0	1.5
		M16	14.60			3.0	2.0
	UD ²⁾	Ø d ₁		Ø d ₁			
		6		1/4	2.0	1.0	
		8		5/16	2.5	1.25	
		10		7/16	3.0	1.5	
		12		1/2	3.0	1.75	
		16		5/8	3.5	2.2	
	ID ²⁾	Ø d ₁	Ø d ₂	Ø d ₁	Ø d ₂		
		M5	10	3/16	1/4"	3.0	1.5
		M6	10	1/4	0.393	3.0	1.5
		M8	12	5/16	0.472	3.0	1.75
		M10	16	3/8	0.638	3.5	2.2

- 1) to be checked by test weldings
- 2) Information and recommendations on this can be found in **DIN EN ISO 14555**.
- 4) When welding on galvanized workpieces we recommend increasing the lift.
- 5) according to **EN ISO 13918**

Welding elements Material: 4.8 (suitable for welding) / A2-50 ⁴⁾	Diameter of welding elements				ARC 500, ARC 800, ARC 1550, IT 50, IT 90, IT 130, IT 1002, IT 2002, IT 3002 Welding gun parameters A 16 ¹⁾		
	metric ⁵⁾		imperial (US)		Insertion depth P in mm	Lift L in mm	
	Stud-diameter in mm	eff. diameter in mm	Stud-diameter (ca.)	eff. diameter in inches (ca.)			
Material of workpiece: Mild steel (suitable for welding) / stainless steel (suitable for welding) ⁴⁾							
		Ø d ₁	Ø d ₂	Ø d ₁	Ø d ₂		
	PS ³⁾	M6	7	1/4	0.21	2.5	1.25
	PS ³⁾	M8	9	5/16	0.28	3.0	1.5
	PS ³⁾	M10	11	3/8	0.35	3.0	1.75
		Ø d ₁	Ø d ₂	Ø d ₁	Ø d ₂		
	US ³⁾	6	7	1/4	9/32	2.5	1.25
	US ³⁾	7.1	9	9/32	3/8	3.0	1.5
	US ³⁾	8	9	5/16	3/8	3.0	1.7
		Ø d ₁	Ø d ₂	Ø d ₁	Ø d ₂		
	IS ³⁾	6	M4	1/4	5/32	2.5	1.25
	IS ³⁾	7.1	M5	9/32	#10 / 3/16	3.0	1.5
	IS ³⁾	8	M5	5/16	#10 / 3/16	3.0	1.5
		d ₁		d ₁			
	SD ²⁾	9.5 / 10		3/8"		3.0	2.0
	SD ²⁾	12.7 / 13		1/2"		3.0	2.5
	SD ²⁾	16		5/8"		3.5	3.0

- 1) to be checked by test weldings
- 2) Information and recommendations on this can be found in **DIN EN ISO 14555**.
- 3) Information and recommendations on this can be found in **DVS 0902** and **DVS 0904**.
- 4) When welding on galvanized workpieces we recommend increasing the lift.
- 5) according to **EN ISO 13918**



The maximum adjustment values which can be set for the insertion depth (3.5 mm) as well as the lift (3 mm) should not be exceeded.




The specified values apply for welding in welding position PA.

Adjusting Lift



The adjustment piece for lift must not be turned by more than 360°.



- 1 - Cap
- 2 - Marking
- 3 - Scale wheel
- 4 - Slotted screw
- 5 - Allen key size 8


- ◆ Screw off the cap (1) at the rear.
- ◆ Use the allen key to turn the adjustment piece for lift counter-clockwise to the selected lift (see table under point 10.3).

The lift can be adjusted in steps of 0.25 mm. (The empty space between 0 and 0.25 mm serves to mechanically balance out the lifting ring construction).


- ◆ Screw on the cap again.
- ◆ You can **reduce** the lift by turning the adjustment piece for lift **clockwise**.
- ◆ You can **increase** the lift by turning the adjustment piece for lift **counter-clockwise**.

Setting the Insertion Depth (Protrusion)

The insertion depth characterizes the overlap size which would be achieved by welding element and base material with seated welding gun before welding. This overlap provides the melt for forming the weld collar.



E = Insertion depth for welding elements with conical face





E = Insertion depth for welding elements with plane face

- ◆ Loosen the wing screw at the welding gun and adjust the insertion depth (see table under point 10.3).

Insertion depth X

Ceramic application

Shielding gas application



- ◆ Clamp the tripod legs with the wing screw.



There must be no friction between welding element and ceramic ferrule.

◆ If so, center the foot piece of the welding gun.



When triggering the welding gun key, the welding gun lifts the welding element always by the same lift value, independent from the position of the welding element.

Assignment stud diameter – electrical current – welding time with lift and protrusion:

Example:

Diameter of the welding element	Welding current	Welding time	
dia. 16 mm	1 300 A	0.65 s	with ceramic ferrule
dia. 12 mm	1 000 A (+ 10 %)	0.45 s	with shielding gas

Optimum parameters for an application may differ from indicated data due to plate thickness, welding position, coatings, type of ceramics ferrules etc.

◆ Based on stud diameter at the welding place, determine welding current and welding time, then lift and insertion depth depending on type of stud tips (to ceramic ferrule or face area). Note the insertion speed!

Example 1:

Diameter of welding element = 16 mm:

Welding current = 1 300 A, Welding time = 0.65 s,

flat stud tip (with alu ball):

lift = 3 mm, insertion depth = 3.5 mm, insertion speed = 100 mm/s.

11 Welding



- ◆ Work according to the *original operating manual of the HBS stud welding unit.*



Danger if used other than for the intended purpose

- ◆ Use the stud welding gun only for ARC stud welding and only in combination with stud welding units from manufacturer:



HBS Bolzenschweiss-Systeme GmbH & Co. KG

Felix-Wankel-Strasse 18
85221 Dachau
GERMANY



- ◆ Always check with the operating manual of your stud welding unit whether this stud welding gun may be used.





12 Troubleshooting



Danger from insufficiently qualified operating personnel

- ◆ Carry out only the work described here on your stud welding unit or stud welding gun.
- ◆ Repairs may only be carried out by appropriately qualified personnel.
- ◆ Inform your dealer or your maintenance department.

Fault	Possible cause	Fault localisation	Fault remedy	Performance
Welding elements not firmly attached	Wrong welding parameters selected	Check adjusted parameters on stud welding unit Check lift of welding gun	Change adjusted parameters Change adjusted parameters	Trained personnel Trained personnel
	Insertion speed of welding element too low	Check lift of welding gun Check welding piston and linear bearing for ease of movement *)	Change adjusted parameters Clean or replace *)	Trained personnel Qualified specialists
Burning marks at the welding element	Chuck defective	Check chuck for possible defects	Replace chuck	Trained personnel
	Lamellas of chuck are not pretensioned	Check lamellas of chuck	Try to bend lamellas if possible, otherwise replace chuck	Trained personnel
Welding gun does not weld	Wrong welding parameters selected	Check lift on the stud welding gun Check protrusion (insertion depth) on the stud welding gun	Change adjusted parameters Change adjusted parameters	Trained personnel Trained personnel
	Control cable defective (no trigger signal available on stud welding unit)	Check control cable for electrical flow at control cable sleeve (Pin 3 and 4) with pressed welding gun trigger *)	In case of no signal: Replace control cable *)	Qualified specialists
	Micro switch defective (no trigger signal available at stud welding unit)	Check control cable for electrical flow at control cable sleeve (Pin 3 and 4) with pressed welding gun trigger *)	In case of no signal: Replace micro switch *)	Qualified specialists
	Welding current cable defective (no contact signal on stud welding unit)	Check, whether welding current cable is connected to stud welding unit in a technically correct way Check welding current cable for electrical flow *)	Connect welding current cable In case of no flow : Replace welding current cable and/or connecting cable *)	Trained personnel Qualified specialists

Fault	Possible cause	Fault localisation	Fault remedy	Performance
Welding gun does not weld	Ground connection defective (no contact signal on stud welding unit)	Check, whether ground cable is connected to workpiece in a technically correct way Check ground cable for electrical flow *)	Connect ground cable In case of no flow: Replace ground cable *)	Trained personnel Qualified specialists
	Stud welding unit defective	Follow the instructions of the connected stud welding unit	Repair required	Factory service or authorised agencies
Welding gun does not lift, in spite of  ,  and 	Short circuit of magnetic circuit of the welding gun	Measure resistance value at control cable connector (18 Ω to 22 Ω) between Pin 1 and Pin 2 *)	Replace control cable connector, control cable and solenoid *)	Qualified specialists
	Solenoid defective	Measure solenoid (18 Ω to 22 Ω) *)	Replace solenoid *)	Qualified specialists
No  display	Magnetic circuit interrupted	Measure resistance value at control cable connector (18 Ω to 22 Ω) between Pin 1 and Pin 2 *)	Replace solenoid or control cable *)	Qualified specialists



Work marked with *) may only be carried out by qualified electricians!

- ◆ Please contact our Service department if none of the measures described remedies the situation.
- ◆ Please use the form „Service & Support“ in the annex to send in the stud welding unit or stud welding gun.

13 Maintenance and Care



Electric shock hazard

- ◆ Never perform maintenance and service work on your stud welding gun while it is connected to the stud welding unit
- ◆ Prior to this disconnect the stud welding gun from the stud welding unit.



Danger from insufficiently qualified operating personnel

- ◆ Carry out only the work described here on your stud welding gun.
- ◆ Repairs may only be carried out by appropriately qualified personnel.
- ◆ Inform your dealer or your maintenance department.

13.1 Cleaning

- ◆ Clean the casing of your stud welding gun with a slightly damp washcloth, when necessary.



- ◆ **Do not use solvents for cleaning.**
These may damage plastic components.

13.2 Inspection and Tests

- ◆ Inspect the chuck before every use.
- ◆ Replace the chuck if you discover burning marks on the welding element and/or on the chuck.
- ◆ Work here in accordance with *point 10 „Preparing the Stud Welding Gun“* in this manual.
- ◆ Before every use, inspect the bellows on the front part of the stud welding gun for proper seating and/or damage.



- ◆ **Never work with damaged or incorrectly seated bellows.**

This will contribute to a long service life of your stud welding gun.


- ◆ Inform your dealer or maintenance department if you discover any damage.
- ◆ Before every use, check that the type designations and adjustment aids on the stud welding gun are still legible.
- ◆ Clean the type plates in the event of soiling.
- ◆ Replace any type plates that are damaged or no longer legible.

13.3 Adjusting the Lift Scale



The lift scale can only be adjusted with connected and switched on stud welding unit.

- ◆ Observe the safety instructions in the operating manual of the connected stud welding unit.
- ◆ Refer here to the operating manual of your stud welding unit.



- 1 - Cap
- 2 - Marking
- 3 - Scale wheel
- 4 - Slotted screw
- 5 - Allen key size 8

- ◆ Screw off the cap at the rear.
 - ◆ Now screw in the lift up to the stop by turning clockwise.
 - ◆ Now screw out the lift step by step by turning counter-clockwise.
 - ◆ Push the welding gun trigger and check if lift is triggered.
 - ◆ Repeat this procedure until a lifting motion at the chuck is visible.
 - ◆ Lock this position with an allen key (size 8).
 - ◆ Loosen both slotted screws.
 - ◆ Adjust the scale wheel by turning and setting the zero position onto the marking.
 - ◆ Then tighten the slotted screws.
 - ◆ Screw on the cap again.
- Now the scaling 'Lift' is adjusted.

14 Storage

- ◆ Store the stud welding gun in a safe and dust-free location when not in use.
- ◆ Protect the stud welding gun from moisture and metallic contamination.



- ◆ Store the stud welding gun only under the following ambient conditions.

Storage temperature:


-5 °C to +50 °C (23 °F to 122 °F)

Relative humidity:

0 % - 50 % at +40 °C (104 °F)

0 % - 90 % at +20 °C (68 °F)

15 Disposal



- ◆ Dispose of the stud welding gun only via the manufacturer or a specialist disposal company.
- ◆ Never dispose of the stud welding gun in the domestic refuse.



Declaration of Incorporation of partly completed Machinery

to Directive 2006/42/EC, Annex II 1 B
(Original Declaration of Incorporation)

Herewith the manufacturer

HBS Bolzenschweiss-Systeme GmbH & Co. KG
Felix-Wankel-Strasse 18
P.O. Box 13 46
85221 Dachau
GERMANY
Phone +49 8131 511-0
Fax +49 8131 511-100

declares for the following product

Machine information: Stud welding gun
Type: A 16
Order No: 93-20-280C
Serial No: 93-20-280C/182XXXX
Year of manufacture: 2018

that the following essential requirements of the above mentioned Directive – including changes to the Directive to be applied at the moment of this declaration – were applied and fulfilled:

Annex I, Article 1, 1.1.2, 1.1.3, 1.1.5, 1.1.6, 1.1.7, 1.2.1, 1.2.2, 1.2.3, 1.2.4.1, 1.2.6, 1.3.1, 1.3.2, 1.3.3, 1.3.4, 1.3.7, 1.3.8, 1.3.9, 1.4.1, 1.4.2.1, 1.5.1, 1.5.2, 1.5.4, 1.5.5, 1.5.6, 1.5.8, 1.5.10, 1.5.11, 1.5.15, 1.5.16, 1.6.1, 1.6.2, 1.6.3, 1.6.4, 1.7.1.1, 1.7.2, 1.7.3, 1.7.4,

that special technical documentation was compiled in accordance with Part B of Annex VII of the above mentioned regulation and will be transmitted, in response to a reasoned request by the national authorities as follows:

The above mentioned documents will be transmitted by e-mail as a data file in German language.

that this partly completed machinery must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of the Directive, where appropriate.

that this incomplete machine complies with corresponding regulations of the following additional EU Directives, including any changes to be applied at the moment of this declaration:


„Electromagnetic compatibility“ 2014/30/EU
Protection targets of the low voltage regulation were kept to appendix I, no. 1.5.1 of the machine regulation.

Persons who are based in the European community and who are authorised to compile the technical documentation:

Name: Heike Otto Address: see manufacturer

Dachau, 02.01.2018

Place of issue, Date



Gregor Gröger (General Manager HBS)

Service & Support

With the return please attach a copy of the filled out form together with the repair number given by HBS! Repairs without repair number will not be processed.

Repair number

(given by HBS)












Company: _____
 Name / Surname: _____
 Street: _____
 City, State and ZIP/Postcode: _____
 Country: _____
 Phone & Fax: _____
 E-mail address: _____

Stud welding unit / stud welding gun
 type of model: _____
 Serial number: _____
 Date of purchase: _____
 Purchased at distributor: _____

Detailed descriptions of errors: _____

Service & Support may be done up to the value of EUR _____ Yes No
 without quotation:
 Could you find any damage / burn marks
 on the cables: Yes No
 on chucks: Yes No
 Are all plug and screw connections tightly fastened *: Yes No
 Are there any burn marks on plug or screw connections: Yes No
 Is there any other visual damage (e.g. cracks, dents): Yes No
 Have you checked the fuses: Yes No

Default on the display of the stud welding unit:

ARC / IT					CD / CDM / SC					
										
										**

Which LED's are illuminated (please mark with a cross)?

Please e-mail or fax this form to service@hbs-info.de or fax: +49 8131 511-100.
 In case a repair is necessary a repair number will be given!

* See also operating manual chapter „Connection“
 ** Doesn't light when using a contact welding gun

Index

A

accessories	12
airborne particulates	7
automatic welding head	11

B

bang	7
basic configuration	12

C

capacitor	11
ceramic application	21
cleaning	36
clothing, non-flammable	8
control cable	19

D

danger from incorrect use	6
Declaration of Incorporation	40
disposal	39
double nipple	19

E

ear protection	9
electrical hazards	9
electromagnetic fields	9

F

fire extinguisher	7
fire hazard	7
form „Service & Support“	35, 41
full-ear hearing protection	8
fumes, harmful to health	7

G

glossary	11
goggles with visor	8

H

hazards for the machine	9
hazards for the operator	9
heart pacemaker	7, 9
helmet	8
hydraulic damping	28

I

insertion depth	28
insertion depth, setting	31
intended use	17, 33

L

lift	28
lift adjusting	30
light arc	11

M

maintenance and care	36
mounting the chuck	23, 26

O

operating manual	12
----------------------------	----

P

protection cap	19
protective apron	8
protective equipment	8
protective equipment, personal	9
protective gloves	8

R

rectifier	11
---------------------	----

S

safety goggles	9
safety goggles with sight glass	8
safety precautions	6
scope of supply	12
serial number	19
shielding gas application	25
storage	39
storage temperature	39
stud feeder	11
stud welding gun	11
stud welding machine	11
stud welding unit	11
symbols used	9

T

tripod leg guidance	19
troubleshooting	34
type plate	19

W

warranty entitlement	18
welding cable	19
welding element	11, 17
welding gun, design	19
welding gun trigger	19
welding parameters	11, 28
workpiece	11

HBS Bolzenschweiss-Systeme GmbH & Co. KG
Felix-Wankel-Strasse 18 • 85221 DACHAU • GERMANY
Phone +49 8131 511-0 • Fax +49 8131 511-100 • E-mail international@hbs-info.com

www.hbs-info.com